



Selection Switch Wiring:

- Switch Common Vend Station 4 TB10-16
- Vend Station 4 Selection Switch C TB10-15
- Vend Station 4 Selection Switch B TB10-14
- Vend Station 4 Selection Switch A TB10-13
- Switch Common Vend Station 3 TB10-12
- Vend Station 3 Selection Switch C TB10-11
- Vend Station 3 Selection Switch B TB10-10
- Vend Station 3 Selection Switch A TB10-9
- Switch Common Vend Station 2 TB10-8
- Vend Station 2 Selection Switch C TB10-7
- Vend Station 2 Selection Switch B TB10-6
- Vend Station 2 Selection Switch A TB10-5
- Switch Common Vend Station 1 TB10-4
- Vend Station 1 Selection Switch C TB10-3
- Vend Station 1 Selection Switch B TB10-2
- Vend Station 1 Selection Switch A TB10-1

- Power Input:**
- TB11-1 Power Input +5VDC
 - TB11-2 Power Input Common (-5VDC)

**ESDI MODEL 110400-NOM
FOUR (4) STATION WATER VENDING MACHINE CONTROLLER W/O PAY STATION
WIRING DIAGRAM**